



Inflatable Working Life Jacket 150N

Model: HXCOY-D150N IMPA: 330166

Technical Specifications

- Type of Buoyancy: Inflatable
- Buoyancy: ≥150N
- **Buoyancy loss:** ≤5%
- Weight: ≤1kg
- Number of Inflatable Chambers: 1
- Main Components: Inflatable Chamber Material: TPU CO2 Gas Cylinder: 33g

Certifications

• Approval: CCS certificate • Standard: ISO 12402-3:2020

Important Note: This life jacket does not meet SOLAS requirements and is intended solely for use by seamen during offshore work activities.



Manufacturer



Dongtai Martian Ship Equipment Co., Ltd.



MARINE SAFETY ESSENTIALS We Offer On-Board Firefighting And Marine Safety Essentials

Disclaimer: Accuracy of all technical data and information are provided to the best knowledge of the manufacturer. Properties, specifications and application parameters are subject to change without notice. The manufacturer does not undertake any liability of any kind whatsoever.





Product Features

- Single chamber inflatable life jacket.
- Ideal for seamen during offshore work activities.
- Capable of manual, oral, and automatic activation.
- Comes with SOLAS reflective tape, oral inflation tube, one rescue whistles, and grabing loop.
- Air chambers will inflate in less than 5 seconds when activated using CO2 air cylinders.

Important Note: The air cylinder has water-activation capability, manual activation is only required if water-activation device is lost or not working. **Pull the cord immediately** when that happens.

Add-On Accessories (Separate Order)



Life Jacket Light Model: HXYD-GD



MARINE SAFETY ESSENTIALS

We Offer On-Board Firefighting And Marine Safety Essentials

Disclaimer: Accuracy of all technical data and information are provided to the best knowledge of the manufacturer. Properties, specifications and application parameters are subject to change without notice. The manufacturer does not undertake any liability of any kind whatsoever.





How To Use HXCQY-D150N Single Chamber Inflatable Working Life Jacket

Read the instructions before use:

- (1) Make sure the 33g CO2 air cylinder is tightly fitted.
- (2) Check every components before donning life jacket.
- (3) Wear it like a vest, make sure to fasten the front buckle, adjust the torso strap as tight and comfortably as possible.
- (4) **Automatic Activation:** Our single chamber inflatable working life jacket is equipped with an automatic inflation mechanism. When the life jacket comes into contact with water, the air chamber will automatically inflate.
- (5) Manual Activation: If the water-activation device is lost or not working, it can be manually activated using a pull cord.
- (6) When loss of buoyancy occurs, use the oral inflation tube to blow air into the air chamber.
- (7) Handwash after use in clean water with mild detergent.
- (8) Do not machine wash, dry clean or use any other cleaning solutions on the life jacket.



MARINE SAFETY ESSENTIALS

We Offer On-Board Firefighting And Marine Safety Essentials

Disclaimer: Accuracy of all technical data and information are provided to the best knowledge of the manufacturer. Properties, specifications and application parameters are subject to change without notice. The manufacturer does not undertake any liability of any kind whatsoever.